

Removing interior Colour Line from R56 JCW

Tools Needed;

- ◁ Plastic Interior Trim Removal Tools
- ◁ T20 Torx Screw
- ◁ T10 Torx Screw
- ◁ Extra Small Allen Key
- ◁ Pliers

1. The first part of this process is to remove some parts of the interior trim surround, this includes the passenger side air vent and also the Speedo surround;

The torx screw at the top unfortunately

Starting not to remove the colour line trims the passenger side is held on with 5 torx screws, two of these are visible behind the air vent we removed and behind the Speedo surround we just removed, the other 3 screws are under the trim, so just open the glove box and these will be visible..

The final part of the process involves removing the ignition/key slot from the trim, this involves removing the plastic trim cover. To do this use one of the plastic trims and prise it off at one side, using a small allen key press the visible metal clip to release the cover, the same process can be used for the other side. Once you remove this you need to unscrew the key slot, this is held in place with 4 T10 Torx screws..